




The premier source of tooling, parts, and accessories for bench top machinists.


## Mounting the Shooting Star DRO on the X3 Mill

The Shooting Star DRO makes a great installation on the X3 mill. These photos and drawings show how to do it.

### *X-Axis Scale*


The X-axis scale mounts across the back of the mill table. Use the mounting hardware furnished with the DRO package.






### ***Y-Axis Scale***

The Y-axis scale mounts under the left side of the table.



### ***Z-Axis***


The Z-axis mounts on the left side of the column.




## Display

The display mounts on the left side of the mill head.







**LittleMachineShop.com**


© 2008 LittleMachineShop.com. All rights reserved.

## Y-Axis Bracket

Revision 2

0000

Sheet 1 of 1



**LittleMachineShop.com**


© 2008 LittleMachineShop.com. All rights reserved.

## Z-Axis Bracket

Revision 1

0000

Sheet 1 of 1



Material: 3/4" x 1/8" Steel Angle Iron

**LittleMachineShop.com**


© 2008 LittleMachineShop.com. All rights reserved.

**Display Bracket**

Revision 3

0000

Sheet 1 of 1



**LittleMachineShop.com**


© 2006 LittleMachineShop.com. All rights reserved.

**Top Z-axis Mount Location**

Revision 0

0000

Sheet 1 of 1



**LittleMachineShop.com**

© 2006 LittleMachineShop.com. All rights reserved.

## Y-AxisMounting

Revision 0

0000

Sheet 1 of 1