




Potentiometer switch is open in the full counter-clockwise (zero speed) position, closed otherwise.

Wire spindle safety switch between K3 and K4.

LittleMachineShop.com

© 2010 LittleMachineShop.com. All rights reserved.

Mini Mill, HF & MM

Revision 0

4509

Sheet 1 of 1